

INTRODUCTION TO THE FORMULASPEED2.0

Fitment & Controls

- Steering Wheel (telescopic & has 2 horizontal positions)
- Seat
- Pedals (multiple position)
- NLS – Disconnect for first sessions if driver has no NLS experience
- Switches (starter, ignition (on/off), rain)
- Brake Bias adjuster
- Reverse lockout (Push it back in!)
- Fire Suppression system
- 6 point restraints

Steering Wheel/ Display Details

The FormulaSPEED2.0 dash displays the following information:

- Lap time
- RPM value
- RPM graph bar
- 5 shift lights
- 4 alarms

- Alarm 1 = Engine temp above 235
- Alarm 2 = Oil temp above 240
- Alarm 3 = Oil press below 40psi (on at idle)
- Alarm 4 = Fuel pressure below 60psi



Green buttons: work as push to talk

Red buttons: operate the easy and intuitive menu.

To enter the menu press twice "MENU/←" (Not used on track)

On Track

- Rev limit = 7200
- 5 Shift lights = 6200, 6400, 6600, 6800, 7000
- No Lift Shift Actuation works best at speed
- H2O temp best at 185-205 deg F. Running below 180 will affect performance
- Oil Temp best at 200-225 deg F. Running below 145 will cause issues
- Oil pressure should be min 55psi @ 6000 rpm (alarm is normally on at idle)
- Fuel pressure should be 65-70psi